



# INSTALLATION INSTRUCTIONS

## ATV Plow Markers

Part Number: 67679  
Application: ATV Snow Plow

### I. Parts List

<u>Description</u>	<u>Qty</u>
<i>Plow Markers</i>	2
<i>HexNut</i>	4
<i>Internal Star Washer</i>	4

### II. Tools Required

- 11/16" Wrench
- 7/16" Drill Bit
- Electric Drill

### III. Installation

1. Drill out the 5/16" hole located on the top outer edge of the plow to a 7/16" diameter hole. **Figure 1**

2. Install the plow markers and attach with the supplied hardware, and torque down to 18 ft-lbs. **Figure 2**

**Plow Marker installation is now complete and should look like figure 2.**



**Figure 1**



**Figure 2**