


AltRider Side Stand Enlarger Foot for the Triumph Scrambler (Air Cooled) INSTALLATION INSTRUCTIONS

Dear Rider,
Thank you for choosing AltRider! Whether a seasoned world adventurer or a first time ADV-Newbie, we welcome you to the AltRider experience. You can install your new product with the utmost confidence. AltRider designs, tests, and manufactures all of its products here in the United States. We are proud to do what we do, and honored to present to you the product of our labors.

Enjoy it, show it off, and most of all, **RIDE IT!**

Venture On,
Jeremy LeBreton



TRIUMPH Scrambler (Air Cooled) Side Stand Enlarger Foot

Package Contents:

- Side Stand Foot
- Hardware Kit
- Instructions

AltRider LLC

Global

mailing: 4000 Aurora Ave N Ste 100
Seattle, WA 98103 USA
phone: 206-922-3618
email: info@altrider.com
web: www.altrider.com

Europe


mailing: Heliumstraat 230
2718 RS Zoetermeer
The Netherlands
email: info@altrider.eu
web: www.altrider.eu

Rev 0.4

MADE IN THE USA



all imagery is property of AltRider


**Kit:****Instructions**

- ① Side stand enlarger Top part
- ② Side stand enlarger Bottom part
- ③ (6) M5 washers
- ④ (2) M5 x 12 button head torx screws
- ⑤ (2) M5 x 10 button head torx screws


Tools necessary:

- ① T25 torx tool
- ② Thread locker






- ① Apply thread locker to the tips of all four screws.
TIP: To make installation easier, have a friend balance on your bike with the side stand off the ground. Or put your bike in gear and lean it against a sturdy wall.



- ③ Slide onto side stand. Place washers between upper and lower plate as shown, three on each side. Hold plates aligned and thread in M5 x 12mm long screws.

Tighten the two 10mm screws at the tip until they are flush with the underside of the bottom plate.



- ② Loosely thread in the two M5 x 10mm long screws through top plate and into bottom plate in locations shown. Only screw in a few threads, screw should not extend below bottom plate.



- ③ Tighten the rear 12mm screws so that the top plate squeezes the side stand tight. The stack of washers prevents over tightening.

After 100 miles/1 hour of riding re-check the screws for tightness.

CONGRATULATIONS!

You've completed your installation. If at any point you have questions about your installation or have any feed back for us, we'd love to hear it. A downloadable version of these instructions can be found at our website. www.AltRider.com

TERMS OF USE, WARRANTY AND LIABILITY WAIVER

AltRider LLC, a Washington company, having its principal place of business in Seattle, WA ("AltRider") offers its motorcycle accessories (the "Product") with the terms, conditions and notices as follows:

Terms of Use

This Product is offered to you conditioned upon your acceptance without modification of the terms, conditions, and notices contained herein. Installation and/or use of this product implies acceptance of all such terms, conditions, and notices. If you do not agree to these terms, do not buy the Product. If you have already bought the Product and do not agree to these terms, return this Product promptly including the packaging and all written materials, to AltRider.

Limitation of Liability and Warranty Disclaimer

You may return your merchandise for a full refund or exchange, less any original or return shipping fees under these conditions:

1. Only if the merchandise is in 100% factory condition. Original manufacturer's packaging and same condition as sold – original boxes, packaging material, instructions, documentation, parts, and attached tags.

2. Only unused, unscratched, uninstalled, undamaged merchandise will be accepted. Do not install equipment until you are sure you want to keep it. Package items carefully in protective materials before returning them. Never ship an item in its original manufacturers packaging – it will arrive damaged. Please use a postal box or other adequate packaging to ensure your return or exchange is not damaged on the way back to AltRider.com.

To read more about our exchanges and returns policy, on the web, navigate to www.altrider.com/index.php/symfony/exchangesAndReturns

Excepting the warranties stated in the preceding paragraph, AltRider hereby disclaims all other warranties and conditions with regard to the Product including all implied warranties and conditions of merchantability and fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof. AltRider does not warrant against damages or defects arising out of use or installation of the Product. Installation instructions are provided for your convenience. AltRider is not responsible for any damages arising out of the installation, improper or otherwise, of the Product. No warranty of any kind, expressed or implied, is made regarding the safety of this Product.

To the extent allowed by law, AltRider shall not be held liable for any direct, indirect, punitive, incidental, special or consequential damages arising out of, or connected with, the use or misuse of this Product. Buyer assumes all risks and liability arising from use of this Product.

Entire Agreement

This document states the entire obligation of AltRider with respect to the Product. If any part of this agreement is determined to be void, invalid, unenforceable or illegal, including, but not limited to the warranty disclaimers and liability limitations set forth above, then the remainder of the agreement shall remain in full force and effect.

Applicable Law

This agreement is governed by the laws of Washington, USA. You hereby consent to the exclusive jurisdiction and venue of the courts of Washington, USA, in all disputes arising out of or relating to the use of this product.

Global Office:

email: info@AltRider.com
phone: +1 206-922-3618
address: 4000 Aurora Ave N
 Ste 100
 Seattle, WA 98103

Europe Office:

email: info@AltRider.eu
address: Heliumstraat 230
 2718 RS Zoetermeer
 The Netherlands

