

FEEL THE HEAT!

RacePace Spare Tire Carrier for Polaris RZR

Part # 01-1109	XP1000 (Fits 2 & 4 Seat Models)	Black
Part # 01-1915	2015+ RZR 900 (Fits 2 & 4 Seat Models)	Black

Congratulations on your purchase of the DragonFire RacePace Spare Tire Carrier! As part of our RacePace modular cage system, this spare tire carrier is a great addition to the OEM roll cage on any Polaris RZR. This easy bolt-on setup will provide you with a lightweight and stylish option for bringing a spare wheel and tire with you on your rides. Be sure to check out the full line of DragonFire Accessories for your Polaris vehicle at your local authorized dealer or online at <http://www.DragonFireRacing.com>

****This product is designed specifically for the Polaris RZR models, but will clamp to any 1.75" tube.
Lug nuts not included***



- Read and understand these instructions before installing product
- Installation may scratch roll cage where clamp is mounted
- Do not use as an anchor point for pulling
- Do not use product if there are any signs of damage

Tools Required

3/16" Allen

Lug wrench

(4) Lug nuts M12-1.50

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and /or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.

Step 1: Place vehicle on a flat and level surface. Place gear selector in "Park" and remove keys from the ignition.

Step 2: Remove clamp half from Spare Tire Carrier mount.

Step 3: Place Spare Tire Carrier on rear cross tube behind seats and above the bed. Attach clamp half, leaving hardware loose for adjustment. (Figure A)

Step 4: Place spare tire on the carrier. Thread lug nuts (not included) on to carrier, tightening until snug. Do not torque at this time.

Step 5: Ensure the tire is resting on the bed and tighten spare tire carrier clamp hardware to 7 ft-lb (84 in-lb). Do not over torque the bolts on the clamp.

Step 6: Torque 4 lug nuts to wheel manufacturer's specs.

Step 7: Installation is complete. Time to ride and enjoy!

Note: For aggressive driving, larger tires and rough terrain; it is recommended to strap the tire to the bed of the vehicle in addition to tire carrier.

ProTip: Periodically check all hardware and re-tighten if needed.

For further assistance please contact us at
customerservice@dragonfireracing.com or 1-800-708-9803.

