

FEEL THE HEAT!

Revision No: 00
Revision Date: 08-14-2018

How to Use The Remote for Light Devices

Part # **11-0040** 4ft Lighted Whip

Part # **11-0041** 6ft Lighted Whip

Congratulations on your purchase of the DragonFire Whip Light! Make sure to check additional DragonFire products for your UTV at your local Authorized DragonFire Dealer or online at <http://www.DragonFireRacing.com>.

Universal Mount Part # 11-0036-Sold Separately - Fits: 1.5"-2" Round Tube

Disclaimer

Off road activities can be hazardous and could lead to injury, dismemberment, paralysis and death. No warranty of representation is made as to the products ability to protect the user from any injury or death. The user assumes that risk. The acceptance and / or use of this merchandise purchased from DragonFire by the customer hereby shall release DragonFire from any and all liability pertaining to the use of such merchandise.



- Read and understand these instructions before installing product
- Do not use product if there are any signs of damage
- Installation May Damage Powder Coat

Tools Required

19mm Wrench


Pre-Installation- Refer to DragonFire Racing website to ensure that you have the laterst version of instructions.

Step 1: Use the 19mm wrench to tighten and secure the Whip Light Mount (**Figure A**).

Step 2: Pull back on the Spring Sleeve to attach the Whip Light on to the Whip Light Mount (**Figure B**).

This Completes the Whip Light Installation.

Note: Ensure Whip Light is connected properly. The red wire is the Positive (+), and the black wire is Negative (-). We recommend that the Whip Light is connected to a rocker switch that is hooked up to the battery.



Power On: Used to power on the whip light. You may also set the current pattern speed to "Slow Motion" by holding the power on button down during a light pattern.

Power Off: Used to power off the whip light. Also used to Auto-Save any modified settings.


Automatic Mode: Automatically plays a set pattern. For set up, press while whip light is off to enter set up menu. press M- or M+ to adjust the LED Pixels. Press the Blue button to adjust the RGB sequence. Press Off to save.

Speed Adjustment: There are 10 different speed settings.

Brightness Adjustment: There are a total of 32 Brightness Levels.

Multi-Color Display: Press one of these buttons while the whip light is on to display the corresponding color.


Pattern/Mode Switch: There are a total of 63 different patterns to choose from.



1: Press and hold for 5 seconds to link the remote to the whip light.

2: Press and hold for 5 seconds to unlink the remote from the whip light.

3: RGB Sequence set-up- While the whip light is off, press auto to enter the setup menu. The first three lights of the Multi-Color display shows the current RGB Sequence. Press the Red, Green Blue buttons until the whip lights display that color. Press Off to save.



For further assistance please contact us at customerservice@dragonfireracing.com , or by phone at 1-800-708-9803.

