

PART #	DESCRIPTION	PART INCLUDED
8022779	AXLE X5CL FRONT 12X100	D
8022778	AXLE X5CL FRONT 15x100/9x100QR	G
8022447	BEARING 18307	B
8022782	ENDCAP X5CL FRONT 12x100PAIR	A,C
8022780	ENDCAP X5CL FRONT 15x100 PAIR	F,H
8022781	ENDCAP X5CL FRONT 9x100QR PAIR	E,I

NOTES

1. Remove end caps by hand, if tight try using a rubber glove or blind bearing puller tool
2. Always install rotor side bearing first
3. Longer end cap installs on rotor side
4. Lube outside facing bearing seals and end cap seals with light grease

