

INSTALLATION INSTRUCTIONS:



NOTE: Failure to follow recommended mounting and installation instructions voids warranty. Manufacturer is not liable for any damage, injury or death that results from improper use and installation of products. By installing these products, user accepts all liabilities, terms and conditions outlined in the Liability & Warranty statement included here: www.giantloopmoto.com/warranty/



DO NOT ATTACH STRAPS TO EXHAUST OR OTHER HIGH-TEMPERATURE MOTORCYCLE COMPONENTS.



- 1** Thread strap end through fastener.
- 2** Pull tight - tension is the key to secure attachment.
- 3** Fasten tight strap end to prong.
- 4** Chain multiple straps together to make various lengths.

0417



www.giantloopmoto.com | 888-358-8347 | Bend, Oregon USA

GO LIGHT. GO FAST. GO FAR.