

# Joker MACHINE

## ADJUSTABLE FOOTPEG INSTRUCTIONS

For technical support contact Joker Machine

2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403

PHONE: 909-596-9690, FAX: 909-596-9693

sales@jokermachine.com, www.jokermachine.com

### FOR ALL JOKER MACHINE ADJUSTABLE FOOT PEGS

**NOTE: USE MEDIUM THREAD LOCKER ON ALL HARDWARE**

**DISCLAIMER: Joker Machine denies any responsibility for any issues that may be caused from failure to use liquid thread locker on all hardware listed below.**

### Tools

5/16 12 Point Wrench or 1/4" Hex Key/Driver

1/8 Hex Key/Driver

Medium Thread Locker

**Installation is easier in some cases if you remove the footpeg from mount first.**

1. Install footpeg to stock footpeg mount using the same hardware from your original peg.  
STOCK PARTS: Pin, retaining clip and spring washer  
(OEM # 50912-74)
2. Loosen 1/4"-20 x 1/4" set screws found on the bottom of some footpegs, and 5/16"-18 12 point screw if footpeg is still together after step 1. This will allow you to adjust the peg.
3. Adjust footpeg to desired position and firmly tighten down 5/16"-18 bolt using medium strength thread locker. Be careful not to strip the screw.
4. Once footpeg is securely in place firmly tighten the 1/4-20 set screws using medium strength thread locker.
5. Use our exclusive 10-24 PITCH ADJUSTMENT SCREW that enables you to change the angle of the peg in order to adjust it to a "level" riding position (if necessary) so the pegs don't appear to "lay down" with time, vibration, etc. Tool needed 5/32 hex key/driver.

