


Pro Chain Tool 3.2 **User Manual**

PN 6460332 **Revision 1, 01/2021** ©2021 Pedro's

www.pedros.com



RPG: The Retracting Pin Guide is a multi-purpose feature found only on Pedro's Tutto and Pro Chain Tools. First, the spring loaded RPG supports the pin up to the face of the chain eliminating broken pins and ensuring perfect alignment every time. Second, for chains with guide pins like Shimano® or Campagnolo®, the RPG encloses the guide pin to prevent loss, bending or breakage, and ensuring perfect installation. Third, the RPG accepts the Peening Bit required for installation of Campagnolo[®] 11-13 speed chains.


Peening Bit and Backer: These components are used for Campagnolo[®] 11-13 speed chains which require a peening operation during installation of the chain rivet.

Guide Pin Sheer Slot: Provides an integrated tool to remove the guide section from installation pins. After pressing the master pin into the chain, simply insert the guide section into the sheer slot and rotate the tool up or down.

Chain Fit: The Pro Chain Tool 3.2 fits all modern chains including including SRAM® AXS® 12-speed, Shimano® 12-speed chains and Campagnolo® 13-speed chains. The replaceable bridge and adjustable bridge positioning ensure compatibility with all current and future chains from single to 13-speed and beyond. Visit pedros.com/chainfit for compatibility info.

The stock bridge position will fit most or all chains. If a different position is required, simply loosen the bridge using a 2mm hex wrench and position as needed. To return to original bridge position push bridge fully forward and tighten screw so bridge is snug but still moveable. Next, wedge the 2mm hex wrench between the bridge and body and gently rotate the wrench to set correct spacing (2.2-2.3mm). Fully tighten bridge into position.


Component List



The Pro Chain Tool 3.2 is a shop quality tool designed to easily adapt to all bicycle chains. This level of flexibility is achieved through use of features such as the RPG and Peening Bit & Backer. While the tool is designed to be simple to use, it is important to understand a few important usage details to prevent damage to the tool or chain. Depending on the chain you are working with, methods for installation, modification, or removal can differ considerably. It is important to read and follow any guidelines provided by the chain manufacturer. The following instructions cover general guidelines for installing, modifying, or removing the most common chain types using a Pro Chain Tool 3.2.

Separating a chain with the Pro Chain Tool 3.2

Installing Chain with Master Link/Installation Rivet



- 1. Place chain onto bridge pressing downward lightly on chain to ensure proper positioning.
- 2. Turn drive knob clockwise advancing drive screw assembly toward chain. RPG will contact chain first ensuring alignment and pin support.
- Continue turning until rivet is fully removed.* For chains using re-usable rivets, make sure to stop press before rivet is fully removed.

*If front edge of drive screw begins contacting chain, do not continue turning. This can damage bridge of tool.


This type of chain is assembled using a special master pin made up of a guide section and a rivet section. Please read and follow any manufacturer instructions when installing this type of chain.



- I. Insert master link into the chain.
- 2. Mount chain onto bridge as described above. Ensure drive screw is positioned to allow master pin to pass RPG.
- 3. Turn drive knob clockwise advancing drive screw assembly forward and surrounding master pin with RPG.

- 4. Continue turning drive knob, pressing rivet section of master pin into chain. Rivet should be centered between the outer plates of the chain when in final position.
- 5. Once rivet is pressed to proper position, turn drive knob counterclockwise to pull drive screw assembly away from chain. Remove chain from bridge.
- 6. Bringing the tool to other side of chain, insert guide section of master link into Guide Pin Sheer Slot. Rotate tool to separate guide section from rivet

How to Service Your Pro Chain Tool 3.2



disassembly. 5. With components disassembled, clean any contaminated parts using rag and Pedro's Degreaser. Inspect each part for damage which may impede proper function. Replace if damaged. Lubricate all threaded and sliding parts using a low viscosity lubricant like Pedro's X Dry or Chainj.

The Pedro's Pro Chain Tool 3.2 is designed to be

I Imm Open-end Box Wrench

• Pedro's Lubricant and/or Grease

Remove drive screw assembly from Main Body. Set

body portion aside. Position 11mm open-end box wrench over two flats at base of Main Drive Screw.

each other counter-clockwise unthreading Main Drive

remain on pin, slide off and set aside. If RPG and spring

remain in drive screw, carefully push RPG rearward to

counter-clockwise rotation. Finish Collar Nut removal

Chain Tool 3.2 features a ball bearing behind the

pin (not shown). Be careful not to lose it during

Using pliers, lightly grip Collar Nut and break free by

by hand. Remove pin from Drive Knob. **The Pro**

serviceable ensuring long service and high


• Rag & Pedro's Degreaser

Screw from Drive Knob.

- Reassembly drive screw assembly. Insert pin into Drive Knob. Slide Collar Nut over pin and thread clockwise onto Drive Knob. Lightly tighten with pliers.
- 7. Slide RPG and return spring over pin with spring positioned between Collar Nut and RPG as shown.
- Insert partially assembled drive knob into rear of drive screw and hand thread clockwise. Using I Imm openend wrench, tighten using moderate force. Check RPG function to ensure components are properly assembled. RPG should slide past tip of pin till coincidence with opening of Main Drive Screw and should return freely.

SPARE PARTS AVAILABLE FOR PURCHASE

Part Number	Description	UPC
6460327	Replacement Bridge, Apprentice and Pro Chain Tool	790983297398
6460340TCT04	Tutto Drive Knob	790983295981
6460340TCT05	Tutto Peening Bit	790983295998
6460340TCT06	Tutto Pins (2 Spares)	790983295363
6460340TCT09	Tutto RPG (Retracting Pin Guide)	790983295356



Campagnolo® II-I3 speed chains require extra installation steps. These steps follow the 6 steps described for "Installing Chain with Master Link/Installation Rivet"

- I. Remove Peening Bit and Backer from base of handle by rotating counter-clockwise using a 6mm hex wrench,
- 2. Position Peening Bit onto front tip of RPG as shown. Ensure chain can be mounted onto bridge without contacting Peening Bit.
- 3. Insert Peening Backer into pocket on body as shown.

- 4. Mount chain onto bridge. Note orientation of chain on bridge. The side from which the guide section was removed should face Peening
- 5. Turn drive knob clockwise until resistance increases. Continue approximately 3/4 of a turn more to peen master link.
- 6. Turn drive knob counterclockwise until Peening Bit clears face of chain. Remove chain from bridge. Remove Peening Bit and Backer from RPG. Return to handle.



Chain Checker Plus II: Chain Wear Check Tool, Chain Hook Tool, & Chainring Nut Wrench

- Precision laser cut design accurately measures 0.5% and 0.75% chain wear. Three point chain wear tool design
- properly isolates pin wear from roller wear. Chain hook tool and chainring nut wrench
- add functional versatility and value.



Quick Link Pliers Chain Master Link Pliers

- Laser cut, heat-treated, dual-sided jaws both install and remove master links.
- Cushioned grips provide comfort and control.



Chain Pig II

Shop Quality, Hands Free, Chain Cleaner

- Pro-grade brushes and super absorbent sponge eat chain grime for breakfast, and are always hungry for
- Surgically enhanced with stainless steel hardware and body sculpting ready for epic drivetrain battles
- Innovative quick-lock closure and drag-free derailleur hook for easy use and hands-free operation

