PRAXIS

M30 386EVO
PRESS-FIT

M30 386EVO Compatibility and Spec

CRANKSET	Compatible with Praxis M30 Based **ROAD** Cranks
FRAME SHELL	BB386 EVO ROAD Frames | 86.5mm WIDTH
FRONT DERAILLEUR	Braze-on or ST Clamp

REQUIRED TOOLS

- Bearing Press Tool
- Loctite Superflex Clear
- Mallet
- Headset Cup Removal Tool

Included Parts

Number	Part	Qty
1.	**28mm** ID X 2mm Dust Cover (stepped cover)	1
2.	LEFT/NON-DRIVE **28mm** I.D PF Bearing	1
3.	Cup Sealing O-ring	1
4.	RIGHT/DRIVE 30mm I.D PF Bearing	1
5.	30mm ID X 1mm Dust Cover	1
6.	30mm ID X 2mm Dust Cover	1
7.	30mm ID X 3mm Dust Cover	1
8.	Wave Washer	1

SAFETY INFORMATION - READ BEFORE RIDE

Since specific tools and experience are necessary for proper installation, it is recommended that the product be installed by a qualified bicycle technician.

Read the service instructions of your crank carefully prior to installing the parts. Loose, worn or damaged parts may cause riding problems and serious injury may occur as a result. If installation and adjustments are not carried out correctly, the chain may come off and this may cause you to fall off the bicycle which could result in serious injury. **Read these instructions carefully, and keep them for later use.**

- Ensure that your BB30/PF30 frame shell is clean. If a BB30 frame, remove the c-clips/bearings so frame shell is empty.
- Conversion BB - Make sure the black O-ring is on the Non-Drive Cup prior to pressing into Non-Drive side.
- Apply **Anti-Seize** to the drive cup threads and smooth taper area before installing.
- Before riding the bicycle, check that there is no play or looseness in the bottom bracket connection. Also, be sure to retighten the crankarms and pedals at periodic intervals.
- If you feel any looseness or 'play' in the bearings, the bottom bracket should be inspected/replaced.
- Be sure to read the instructions for your front chainrings/crank in conjunction with these service instructions.
- **Do not wash the bottom bracket with high-pressure jets of water.**
- For maximum performance it is required to remove and periodically inspect/clean your Praxis Works bottom bracket.
- **Parts are not guaranteed against natural wear or deterioration resulting from normal use.**
- For any questions regarding methods of installation, adjustment, maintenance or operation, please contact a professional bicycle dealer or call Praxis Works.
- Praxis Works assumes no responsibility for damages or injury related to improperly installed components.

READ THE STEP BY STEP INSTRUCTIONS PROVIDED ON THE OTHER SIDE.

WARRANTY

- Praxis Works Bottom Bracket products are warrantied to be free from defects in materials or workmanship for two years after original purchase. The warranty is non-transferable and valid to the original purchaser of the product only.
- Any attempt to modify the product in any way such as drilling, grinding or painting will void the warranty.
- This warranty is not valid for "abused" or neglected products, or products that are damaged by improper installation.
- If a defect is found, our entire liability and your sole remedy shall be, at our option, free repair or replacement of the Praxis product.
- Except as expressly required by law, Praxis Works shall not be held liable for any indirect, special, or consequential damages.

THIS WRITTEN EXPRESS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, IMPLIED OR EXPRESSED. This warranty gives you specific legal rights, and you may also have other rights which vary state to state. **For more information on warranty policy and instructions for completing a warranty claim, check out the Full Warranty Policy found at our website. www.praxis-works.com**


LEFT/NON-DRIVE 28mm

RIGHT/DRIVE 30mm

TOOLS REQUIRED

SUPERFLEX RTV
ROOM TEMP VULCANIZING

PRESS

MALLET

CUP REMOVER

BB & FRAME PREPARATION

1 Clean the BB shell with solvent to remove any grease

Clean

2 Use Loctite Superflex RTV Silicone Adhesive (Room Temp Vulcanizing) for all frame materials (or similar RTV adhesive)

**3** Spread a *thin coat* of RTV silicone around the BB shell and on the BB

LEFT/NON-DRIVE BB Cup   **RIGHT/DRIVE BB Cup**

Next page INSTALLATION.....

BOTTOM BRACKET INSTALLATION

- Press all BB Cups using a professional press tool
- Press all BB Cups flush against the bottom bracket shell
- **Press BB Cups one at a time**

1 Press the 28mm ID bearing into the frame's **Left/Non-Drive side**

2 Press the 30mm ID bearing in the frame's **Right/Drive side**

3 See next page to find correct Dust Covers for your crank. Lightly grease underside of Dust Covers and place them over bearings **with Praxis logos facing outward**. Now you can install the crank

Both BB Cups must be pressed flush against the BB shell

BB REMOVAL

1. Pull the headset removal tool **through the Right/Drive cup** until you hear two clicks, then hammer out the Drive BB Cup

2. Feed the headset removal tool in **from the Drive side** until it contacts the Non-Drive Cup, then hammer out that BB Cup

Use **Park Tool RT-1 Headset Removal Tool** or a similar tool to remove BB cups from BB shell

CRANK INSTALLATION

Please see CRANK instructions at **www.praxiscycles.com/manuals**

Only 1 cover per side!

LEFT/NON-DRIVE
28mm I.D.

(Stepped Cover)

RIGHT/DRIVE
30mm I.D.

RIGHT/DRIVE
Wave Washer

**NEXT PAGE FOR
DUST COVER GUIDE**

REFERENCE
FRAME BB SPECS

86.5MM WIDTH

46MM DIAMETER

386EVO
PRESS FIT

BB DUST COVER GUIDE

ROAD M30	WIDTH	CRANK	LEFT 28MM COVER	LEFT CUP SPACER	RIGHT CUP SPACER	RIGHT 30MM COVER
BSA	68	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm
T47 E.B.	68	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm
T47 I.B.	85.5	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm
BB86	86.5	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm
✱ 386EVO	86.5	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm
BB30/PF30	68	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm
BBRight	79	ROAD DM	2mm	-	-	1mm
		ROAD DM "GR"	2mm	-	-	3mm
		ROAD NON-DM	2mm	-	-	2mm

"DM" = DIRECT MOUNT SPIDER *(Removable Spider)*

"NON-DM = NOT DIRECT MOUNT SPIDER *(Pressed-On Spider)*

"DM GR" = DIRECT MOUNT SPIDER - GRAVEL CRANK *(Removeable Spider "GR" crank)*