


Arctic Cat® Wildcat 4

Installation Instructions - Accessory Kit

Aluminum Skid Plate Extension Kit

(p/n 1436-925)




■ **NOTE:** Read these Installation Instructions thoroughly before beginning the installation process. Retain these Installation Instructions for future reference.

Application: Wildcat 4

Kit includes:

Ref. No.	p/n	QTY	DESCRIPTION
1	*	15	U-Nut
2	*	15	Shoulder Screw (11 x 6 mm)
3	2441-372	1	Left Rear Center Skid Plate
4	2441-373	1	Right Rear Center Skid Plate
5	0541-974	8	Protective Foam
N/A	0453-911	1	Instruction

* Included in Hardware Kit (p/n 0541-973)




■ **NOTE:** This kit is an extension and requires Aluminum Skid Plate Kit (p/n 1436-923) to give full under carriage protection for a Wildcat 4. Be sure to install this kit before installing the front skid plate sections.

1. Remove and retain all torx-head screws securing the existing plastic center and rear skid plates to the frame.

■ **NOTE:** All measurements are measured in inches.

2. Apply Rear Center Plate Protective Foam strips to Rear Center Skid Plates using the positions below. See Fig. 1.


Fig. 1



3. Install five U-Nuts onto the left rear center skid plate where it will connect with the right rear center skid plate.

4. Install five U-Nuts onto the left rear center skid plate and five U-nuts onto the right rear center skid plate where they will connect with front center skid plates from the Aluminum Skid Plate Kit (p/n 1436-923). See Fig. 2.

Fig. 2




ROV-356

■ **NOTE:** If installing Aluminum Side Guards, secure them to the skid plates at this time according to the instructions in those kits.

5. Loosely secure the left rear center skid plate to the frame using the existing torx-head screws from step 1. See Fig. 3.

Fig.3




ROV-343

6. Loosely secure the right rear center skid plate to the frame using the existing torx-head screws (from step 1).

7. Secure the two skid plates together using five Shoulder Screws (11 x 6 mm). See Fig. 4.

Fig. 4




ROV-342

■ **NOTE:** Proceed to instructions for installing the Aluminum Skid Plate Kit (p/n 1436-923); then proceed to step 8.

8. Secure the two skid plate kits together using ten Shoulder Screws (11 x 6 mm); then tighten all screws securely. See Fig. 5.

Fig. 5



ROV-341