



# LED FENDER BLADES™

## PARTS INCLUDED

- 2 Fender Blades
- 1 Installation Kit

### INSTALLATION INSTRUCTIONS:

Note: Ideal installation temperatures are between 70°F to 100°F (21°C to 38°C). The minimum application temperature is 50°F (10°C).

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has had time to cool before installation.
2. Set parking brake and/or chock wheels to prevent movement of the motorcycle.

Note: Installation is identical for left and right sides of the motorcycle.

3. Remove stock taillight lens.
4. Plug the Fender Blade light into the empty 3 pin connection on the taillight base to test function. Verify Run, Brake and turn signals are working as intended. Fig.1
5. Unplug light from taillight base.
6. Test fit light along the bottom edge of rear fender(s). Part should be centered left to right and wire channel should hook on bottom edge of fender. Fig.2
7. Take note of final position, it may be helpful to use masking tape to mark the final location.



FIG.1



FIG.2

8. **ATTENTION: Thoroughly clean the mounting surface with denatured alcohol to remove all wax, oil, and residue.**

NOTE, New motorcycles are delivered from the factory covered in protective oil. Remove it before installing this product.

NOTE, Do not install if the temperature is below 50° F. The adhesive will not cure properly.

9. Remove tape liner from light and press into place with firm pressure, holding for 30 seconds. Bond strength will increase over time; approximately 50% of ultimate bond strength will be achieved after 20 minutes, 90% after 24 hours and 100% after 72 hours. Be most cautious during this time.
10. Route wire along inside surface of the fender to meet the factory wire harness at the taillight base.
11. Feed connector into taillight base through pre-existing hole in fender. It may be helpful to remove or loosen the taillight base from the fender temporarily. Fig.3
12. Plug 3-pin connector into open location on taillight base. Fig.4
13. Re-install taillight lens.
14. Secure wire along inside of fender using included cable ties and retainers. It is critical to keep the wire away from the moving tire.
15. Repeat for other side.

G0040041 REV. -

### WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

### CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

### ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

### NOTE:

Ciro® warrants that products sold hereunder to the original purchaser, if maintained and operated under normal conditions, shall be free from any defects in materials and workmanship for a period of (3) years from date of purchase, and a lifetime warranty against LED failure.

Ciro will have no obligation if the customer cannot show proof of purchase.

Warranty will not be granted unless the part is properly installed and maintained.

Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products.

Please visit our website [Ciro3d.com](http://Ciro3d.com) for our complete warranty policy.

**CIRO3D.COM**



FIG.3



FIG.4