

Custom Dynamics® License Plate Relocation Kit Installation Instructions

We thank you for purchasing the Custom Dynamics® License Plate Relocation Kit. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-LPR-KIT

Package Contents:

- License Plate Relocation Kit (1)

Fits: 1991-2013 Harley-Davidson® Electra Glide Classic (FLHTC), Electra Glide Standard (FLHT), Electra Glide Ultra Classic (FLHTCU), Ultra Limited (FLHTK), 1991-2013 Road King (FLHR), Road King Classic (FLHRC), 1986-2017 Heritage Classic (FLSTC),1993-1996 Deluxe (FLSTN) and 1999-2003 Road Glide (FLTR) with rear Flat Style OEM turn signals.



ATTENTION



Please read all Information below before Installation

<u>Warning</u>: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

<u>Safety First</u>: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

<u>Important</u>: Ambient install temperature must be 60 degrees F or higher. Allow 24 hours for tape to cure before washing or prolonged use of vehicle.



Installation:

- 1. Remove motorcycle seat and disconnect the negative [-] battery cable from the battery
- Remove the taillight from the rear fender by removing the two screws on either side of the taillight and disconnecting the wiring harness connector. Lay the taillight assembly facedown on a scratch free surface.
- 3. Disconnect the left and right rear turn signal wiring harnesses.
- 4. Remove the Turn Signal Bar from the rear fender by removing the 2 mounting bolts from the underside of the fender. See Photo 1. On some models, If the bike has been lowered the turn signal mounting bolts can be accessed by completely removing the taillight mounting base.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST


Installation Instructions - Page 2.

Installation Continued:

- 5. With the Turn Signal Bar removed, clean the area between the taillight and the bottom of the fender with the denatured alcohol.
- 6. Place the License Plate Relocation bracket against the fender and align the mounting tab holes with the mounting holes in the fender. Make sure the License Plate Relocation Bracket is straight and center on the fender. Refer to Photo 2.

NOTE: The foam support pad on the back of the bracket needs to sit flush and tight against the fender (Refer to Photo 3) as well as the mounting tabs. It may be necessary to bend the mounting tabs on the License Plate Relocation bracket slightly by hand to match the fender radius.

- Using a grease pencil, Mark the top and the sides of the foam support pad on the fender for reference.
- 7. Remove the red protective film from the foam support pad. Using your reference marks from the previous step, place the License Plate Relocation bracket on the fender and press in the center making sure the foam support pad adheres to the fender. The mounting tab holes on the License Plate Relocation bracket should be aligned with the mounting holes in the rear fender.
- 8. Reinstall the Turn Signal Bar on the rear fender with the License Plate Relocations bracket between the Turn Signal Bar and the fender.
- 9. Connect the turn signal wiring harnesses.
- 10. Reinstall the taillight.
- 11. Connect the negative battery cable to the battery and reinstall the seat.
- 12. Test all lighting for proper operation before riding.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST