


Custom Dynamics® Harley Universal Wiring Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Harley Universal Wiring Adapter. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: UNIV-ADAPTER

Package Contents:

- HD Universal Wiring Adapter



Fitment: 1996-2017 Softails (except Breakout, Slim/Slim-S & Blackline), 1997-2017 Dynas (except FXDB & FXDWG), 1997-2013 Touring (except Street Glide & Road Glide Custom), and 1999-2003 Sportsters, 2010-2013 HD Trikes; 2011-2013 Road Glide Ultra



ATTENTION



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

<u>Safety First</u>: Make sure the bike is parked on a level surface and bike's mechanical components are cool to the touch.

Installation:

- 1. Locate 8 pin connector under seat of bike.
- 2. Unplug connectors and plug in Adapter.
- 3. Connect wires as needed using Posi-Taps.

Black—Ground


Blue - Running

Red— Brake

Brown-Right Turn

Purple—Left Turn

- 4. Check operation of all lights.
- 5. Re-install seat.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST