

GUIDE SETUP INSTRUCTIONS

1. Remove top guide by removing the front top guide nut with a 4mm hex (never adjust the rear T25 bolt).
2. Set slider in the highest position (inserted a 4mm into the hole on the bottom left of the top device with the chain link symbol and backed it out anti-clockwise)
3. Hold backplate directly against ISCG05 tabs. Check for clearance between the back side of the bashplate/guide and the bike frame (use included 2.5mm spacers if necessary to space the backplate away from the frame).
4. Rotate backplate until slider adjustment bolt is directly above the crank axle and torque bolts to 5Nm
5. With crankset and chain installed, use spacer shim block to measure clearance between back plate and chain
6. Determine the corresponding number of chainline shims required
7. If more than 5 shims are required, install the supplied 2.5mm washers behind the backplate and return to step 2
8. Assemble top guide with spacers and tighten bolt to 3Nm
9. Insert a 4mm hex through the hole in the inner top guide, loosen height adjustment bolt and lower the tool onto the chain. Torque to 3Nm to set height.

BASH REPLACEMENT INSTRUCTIONS

1. Remove Bash Guide from bike
2. Remove bolt retaining clip from rear bash plate bolt by pushing a 4mm hex through the bolt from the backside of the guide.
3. Remove Bash bolts using a 5mm hex
4. Select desired bash plate and reinstall bash bolts to 6Nm
5. Reinstall bolt retaining clip on the rear bash plate bolt
6. Reinstall Bash Guide onto bike