

YOSHIMURA

RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA., 91710 · (800) 634-9166 · (909) 628-4722 · FAX (909) 591-2198 **WWW.yoshimura-rd.com**

FENDER ELIMINATOR KIT

070BG121090 Honda Navi






THIS PRODUCT IS NOT DOT APPROVED.

Yoshimura R&D of America, Inc. is not liable or responsible for any resulting event caused by the installation of this product. Check with local laws and regulations for compliance prior to installation and use. This product is not intended for use on public highways.





Removal

- 1. Remove seat.
- 2. Locate and disconnect license plate light and turn signal wires.
- While securely supporting the stock fender assembly, remove the two bolts securing the fender assembly to frame. Carefully remove the stock fender assembly making sure not damage the license plate light and turn signal connectors.

Note: The stock bolts will be used again for the Yoshimura Fender eliminator kit

 Disassemble the stock fender assembly and remove left and right turn signals along with the stock wire grommet.

Note: The stock grommet will be used on Yoshimura Fender eliminator kit


5. Cut the stock license plate light connector from the stock fender assembly. Be sure to cut at least a 6" section of wire from the connector.

Installation

 Install 070BG-LH-K1, Yoshimura license plate light onto 12109-FEBKT, Yoshimura fender bracket using M4X6BHS, 4mm button head screws provided in the kit.



2. Install stock grommet onto the *12109-FEBKT*, Yoshimura fender bracket as shown below.



3. Secure 12109-FEBKT, Yoshimura fender bracket to frame using 8MMLN, 8mm lock nut with the 8MMWASHER-SS, 8mm washer and the stock bolts.



4. Using the *BN-SSS-22-18*, solder shrink connectors provided in the kit, connect Yoshimura license plate light wires to the stock license plate light wires as follows:

Red -to- Green Black -to- Brown


- a) Strip the stock fender light wire ends 1/4" - 1/2" and insert into BN-SSS-22-18, Solder Shrink connectors provided in the kit.
- b) Center the spliced wire ends in the middle and using a heatgun or lighter, apply heat evenly on the outer edges of the butt connector to shrink and hold wires in place.
- c) Making sure that the stripped ends are centered, heat the center of the butt connector evenly until the solder begins to liquify.
- d) Allow to cool completely and tug both ends of the wires to verify that connection is secured

Scan for link to Solder Shrink connector instruction video.



5. Install the stock left and right turn signals onto 12109-TSB-L/R, turn signal brackets using the stock hardware.

6. Install12109-TSB-L/R, turn signal brackets and 070BG-LPF, license plate frame using M6X16BHS and M6X14BHS, 6mm button head screws as shown.



- 7. Route license plate light and turn signal wires through the *12109-FEBKT*, Yoshimura fender kit and under the seat and reconnect.
- 8. Re-install seat.
- 9. Check for proper function of license plate light, turn signals, brake light, and that all brackets and components are secure prior to riding.